

## All Purpose Cleaners

Article No. 16781 Aloe & Green Tea

Article No. 16783 Lavender

Article No. 16782 Lemon

Article No. 16784 Orange Citrus  
(710 mL/24 fl. oz.)

Watkins Natural All-Purpose Cleaners effortlessly remove dirt and grime from most surfaces in your home. You'll find hundreds of uses for this powerful plant-based formula. No rinsing required, simply spray and wipe away with a dry cloth. A great alternative to harsh and toxic chemical cleaners. Powerful enough to remove even your toughest dirt, yet gentle enough for your loved ones, your home and the environment.

### This product is ideal for cleaning:

- Appliances
- Counter Tops
- Fixtures
- Floors
- Sealed Granite
- Sinks
- Stainless Steel
- Tile
- Walls

Everyday choices affect the health of our families and our environment. Watkins Premium Natural Cleaning Products feature plant-based formulas that are:

- Ammonia Free
- Animal Ingredient Free
- Benzene Free
- Biodegradable
- Boron Free
- Butyl/Ethyl Cellosolve Free
- Chlorine Free
- Diethylene Ether Free
- Dye Free
- Formaldehyde Free
- Isopropanol Free
- Kerosene Free
- Mineral Spirit Free
- Never Tested On Animals
- Non-toxic
- Petrochemical Free
- Phosphate Free
- Phosphoric Acid Free
- Propylene Glycol Free
- Sodium Lauryl Sulfate Free
- Sulfuric Acid Free



Many All-Purpose cleaners contain toxins that can be inhaled. Ammonia-based cleaners can irritate the skin, eyes and respiratory system. Minimize your family's exposure to these harmful toxins with Watkins Natural All-Purpose Cleaners.

### Tips

- Spray a small amount of Watkins Natural All-Purpose Cleaner on a soft cloth and gently rub cloth over switch plates to remove smudges and fingerprints.
- Never dust using a dry towel, this method will only relocate dirt into the air or onto the floor. For optimal dusting, lightly dampen a micro fiber cloth or paper towel with Watkins Natural All-Purpose Cleaner.
- To naturally clean your microwave place a bowl of water with a few drops of lemon juice in the microwave and run on high for one minute. Next spray Watkins Natural All-Purpose Cleaner on the surface and wipe away crusted food and grease.
- To clean ceiling fans, use a long-handled brush dampened with Watkins Natural All-Purpose Cleaner.
- Clean appliance knobs, cracks and grooves with a cotton swab dipped in Watkins Natural All-Purpose Cleaner. Before cleaning any appliance please remember to unplug it.